SECTION IDX
ALPHABETICAL INDEX

Numerics

3rd position switch AT-98

A

A/C air flow ATC-30, MTC-26
A/C component layout ATC-21, MTC-21
A/C compressor clutch removal and installation ATC-124, MTC-83
A/C compressor precaution ATC-9, MTC-8
A/C compressor special service tool . ATC-12, MTC-12
A/C HFC134a (R134a) system precaution ATC-4, MTC-4
A/C HFC134a (R134a) system service procedure ATC-120, MTC-80
A/C HFC134a (R134a) system service tools .. ATC-12, MTC-13
A/C HFC134a system service equipment precaution ... ATC-9, MTC-9
A/C lubricant (R134a) ATC-22, MTC-22
A/C operational check MTC-36
A/C system description (auto A/C) ATC-25
A/C trouble diagnoses (auto A/C) MTC-28
A/T fluid checking AT-17
A/T fluid replacement AT-18
A/T fluid temperature sensor AT-108
A/T IND - Wiring diagram DI-39
A/T shift control system AT-251
A/T shift lock system AT-254
A/T shift lock system - Wiring diagram AT-255
A/T trouble diagnoses AT-43
A/T Wiring diagram AT - 1ST AT-122
A/T Wiring diagram AT - 2ND AT-127
A/T Wiring diagram AT - 3RD AT-132
A/T Wiring diagram AT - 4TH AT-137
A/T Wiring diagram AT - CAN AT-96
A/T Wiring diagram AT - ENG SS AT-117
A/T Wiring diagram AT - FTS AT-105
A/T Wiring diagram AT - LPSV AT-157
A/T Wiring diagram AT - MAIN AT-195
A/T Wiring diagram AT - OVRCSV AT-178
A/T Wiring diagram AT - PNP/SW AT-99
A/T Wiring diagram AT - SSV/A AT-163
A/T Wiring diagram AT - SSV/B AT-168
A/T Wiring diagram AT - TCCSIG AT-149
A/T Wiring diagram AT - TCV AT-143
A/T Wiring diagram AT - TPS AT-174
A/T Wiring diagram AT - VSS A/T AT-111
A/T Wiring diagram AT - VSSMTR AT-184
Accelerator control system ACC-3
Accelerator pedal position (APP) sensor EC-555, EC-562, EC-578
Accelerator pedal released position learning EC-88
Air bag SRS-3
Air bag disposal SRS-43
Air bleeding (hydraulic clutch) CL-7
Air cleaner and air duct EM-14
Air cleaner filter EM-14
Air cleaner filter replacement MA-15
Air conditioner cut control EC-26
Air flow meter - See Mass air flow sensor EC-181, EC-190
Air mix door control linkage adjustment ATC-114, MTC-39, MTC-75
Air mix. door motor ATC-114
Air spoiler, rear EI-30
Alternator SC-20
Ambient sensor ATC-100
Angular tightening application EM-3
Antenna - See Power antenna AV-12
APPS1 - Wiring diagram EC-557
APPS2 - Wiring diagram EC-564
APPS3 - Wiring diagram EC-580
ASC/BS - Wiring diagram EC-529
ASC/SW - Wiring diagram EC-521
ASCBOF - Wiring diagram EC-639
ASCD EC-27
ASCD (automatic speed control device) ACS-2
ASCD brake switch EC-527, EC-638
ASCD indicator lamp EC-648
ASCD steering switch EC-519
ASCIND - Wiring diagram EC-649
Audio AV-4
Automatic transmission fluid replacement MA-21, MA-23
AWD - Wiring diagram TF-17
AWD control unit inspection table TF-21
Axle MA-28

B

Back door BL-71
Back door window GW-15
Back window GW-15
BACK/L - Wiring diagram LT-28
Back-up lamp LT-28
Back-up lamp switch (M/T) MT-13
Basic inspection EC-70
Battery/Starting/Charging System Tester SC-6, SC-12, SC-22
Baulk ring (M/T) MT-20
Block heater EM-81
Blower motor ATC-106, MTC-43, MTC-46, MTC-66
Blower resistor MTC-67
Blower unit ATC-104, MTC-64, MTC-66
Boring/horning cylinder block EM-102
Brake fluid level MA-26
Brake inspection MA-26
Brake lines and cables inspection MA-26
Brake pedal BR-6
Brake switch EC-550
BRK/SW - Wiring diagram EC-551
Bulb specifications LT-67
Bumper, front EI-14
Bumper, rear EI-16

C

Camshaft EM-37
Camshaft inspection EM-40
Camshaft position sensor (PHASE) EC-318
CAN - Wiring diagram EC-163, LAN-23, LAN-40, LAN-56, LAN-77, LAN-94
CAN communication ... EC-29, EC-162, AT-32, AT-95, TF-13, TF-36, DI-6
CHARGE - Wiring diagram SC-21
Charging system SC-20
Chassis and body maintenance MA-20
CHIME - Wiring diagram DI-45
Circuit breaker PG-12
Closed loop control EC-23, EC-476
Clutch cover CL-14
Clutch disc CL-14
Clutch master cylinder CL-8
Clutch operating cylinder CL-10
Clutch pedal CL-5
Clutch release bearing CL-12
Clutch release mechanism CL-12
Clutch withdrawal lever CL-12
Coil spring (rear) RSU-10
Collision diagnosis SRS-49
Combination meter DI-4
Combination switch LT-24
Component Location (auto A/C) MTC-29
Compression pressure EM-62
Compressor clutch removal and installation . ATC-124, MTC-83
Compressor special service tool ATC-12, MTC-12
Condenser ATC-129, MTC-89
Connecting rod EM-100
Connecting rod bearing clearance EM-104
Connecting rod bushing clearance EM-100
CONSULT-II for engine EC-123
Control lever (M/T) MT-14
Control unit ATC-99, MTC-63
Control units (terminal arrangement) PG-46
Converter housing installation AT-378
COOL/F - Wiring diagram EC-484
Coolant replacementVQ35DE MA-13
Cooling circuit (engine) CO-6
Cooling fan CO-18
Cooling fan motor EC-493
Cooling fan relay EC-493
Coupling sleeve (M/T) MT-20
Cowl top EI-19
Cowl top cover EI-19
Crankshaft EM-82
Crankshaft position sensor (POS) EC-310
CVT fluid checking MA-21
CVT fluid replacement MA-22
Cylinder block EM-81
Cylinder block boring EM-103
Cylinder head EM-62
Cylinder head bolt tightening EM-65

D

Data link connector EC-659
Desiccant Assembly ATC-29, ATC-130, MTC-25, MTC-90
Diagnosis sensor unit SRS-42
Diagnostic trouble code (DTC) for OBD system . EC-8, EC-51
Diagnostic trouble code (DTC) inspection priority chart EC-100
Differential gear (FF M/T) MT-23
Door glass GW-56, GW-59
Door glass Fitting Adjustment GW-56, GW-59
Door lock BL-65, BL-68
Door trim EI-32
Door, front BL-19
Door, rear BL-19
Drive belt EM-11
Drive shaft MA-28
Drive shaft (front) FAX-13
Drive shaft (rear) RAX-20
Driver air bag SRS-32
Dropping resistor (A/T) AT-161
DTC work support EC-133
Duct and grilles ATC-116, MTC-76

E

ECM input/output signal EC-115
ECM power supply EC-154, EC-419
ECM relay EC-161
ECM/PW - Wiring diagram EC-420
ECTS - Wiring diagram EC-206
Electric sunroof RF-10
Electric throttle control actuator EC-427, EC-429, EC-443
Electrical load signal circuit EC-625
Electrical unit PG-46
Electrical units location PG-41
Electronic ignition (EI) system EC-24
Engine control circuit diagram EC-113
Engine control component parts location EC-107
Engine control module (ECM) EC-416
Engine control system diagram and chart EC-21
Engine coolant CO-8
Engine coolant temperature sensor (ECTS) ... EC-204, EC-218
Engine fail-safe system EC-102
Engine oil LU-6
Engine oil filter replacement MA-17
Engine oil precautions GI-7
Engine removal EM-73
ETC1 - Wiring diagram EC-430
ETC2 - Wiring diagram EC-439
ETC3 - Wiring diagram EC-444
EVAP canister EC-33
EVAP canister purge volume control solenoid valve EC-348, EC-504
EVAP canister vent control valve EC-355, EC-512

EVAP control system (small leak) diagnosis .. EC-338, EC-380, EC-388
EVAP control system pressure sensor EC-362, EC-365, EC-372
EVAP control system purge flow monitoring diagnosis EC-332
EVAP vapor lines inspection MA-19
Evaporative emission (EVAP) system EC-30
Evaporator ATC-131, MTC-91
Exhaust manifold EM-20
Exhaust system EX-2
Exhaust system inspection EX-2, MA-20
Expansion valve ATC-132, MTC-92
Exterior EI-20, EI-21, EI-23, EI-24, EI-25, EI-28, EI-30, EI-31

F

F/FOG - Wiring diagram LT-37
F/PUMP - Wiring diagram EC-614
Fan control amp. ATC-108
Fan switch ATC-29, MTC-46
Final drive (FF M/T) MT-23
Finisher, interior - See Trim EI-32
Finisher, rear panel EI-31
Floor trim EI-39
Flow charts GI-26
Fluid temperature sensor (A/T) AT-108
Fluorescent leak detector ATC-133, MTC-92
Flywheel (clutch) CL-14
Flywheel runout EM-107
Fog lamp, front LT-36
Fork rod (M/T) MT-22
Freeze frame data EC-52
Front bumper EI-14
Front door BL-19
Front Door Trim EI-32
Front fog lamp LT-36
Front passenger air bag SRS-37
Front seat SE-17
Front seat belt SB-3
Front seat belt pre-tensioner SB-2, SRS-3, SRS-41
Front side air bag SRS-38
Front suspension FSU-6
FTTS - Wiring diagram EC-281, EC-286
FUEL - Wiring diagram EC-268, EC-275
Fuel cut control (at no load high engine speed) . EC-25
Fuel filler lid BL-75
Fuel filter replacement FL-4
Fuel gauge DI-4
Fuel injection system EC-266, EC-273
Fuel injector and fuel tube EM-30
Fuel level sensor EC-399, EC-401, EC-403
Fuel line inspection FL-3, MA-15
Fuel precautions GI-5
Fuel pressure check EC-90
Fuel pressure release EC-90
Fuel pump EC-613
Fuel pump and gauge FL-4
Fuel pump relay EC-618
Fuel system FL-3
Fuel tank FL-11
Fuel tank temperature sensor EC-279, EC-285
Fuel tank vacuum relief valve EC-33
Fuse PG-12
Fuse and fusible link box PG-50
Fusible link PG-12

G

Gauges DI-4
Gear components (M/T) MT-20
Generator SC-20
Generator - See Alternator SC-20
Generic scan tool (GST) EC-135
Glass GW-56, GW-59
Grille - See Exterior EI-18
Ground distribution PG-13

H

H/LAMP - Wiring diagram LT-8
Harness connector PG-44
Harness layout PG-21
Headlamp LT-4
Headlining - See Roof trim EI-40
Heated oxygen sensor 1 .... EC-226, EC-233, EC-243, EC-448, EC-454
Heated oxygen sensor 1 heater EC-169
Heated oxygen sensor 2 .... EC-251, EC-258, EC-460, EC-468
Heated oxygen sensor 2 heater EC-175
Heater and cooling unit (Heater core) ATC-110, MTC-70
Heater unit (heater core) ATC-115, MTC-73
HFC134a (R134a) system precaution . ATC-4, MTC-4
HFC134a (R134a) system service procedure ATC-120, MTC-80
HFC134a (R134a) system service tools ATC-12, MTC-13
HFC134a system service equipment precaution ATC-9, MTC-9
HO2S1 - Wiring diaram EC-228, EC-236, EC-246
HO2S1H - Wiring diagram EC-171
HO2S2 - Wiring diagram EC-253, EC-261, EC-463, EC-471
HO2S2H - Wiring diagram EC-177
Hood BL-12
Horn WW-18
HORN - Wiring diagram WW-18
How to erase DTC for OBD system EC-59

I

IATS - Wiring diagram EC-200
Identification ATC-10, ATC-11, MTC-10, MTC-11
Idle air volume learning EC-88
Idle mixture ratio EC-77

Idle speed EC-70, EC-77
Idle speed control (ISC) EC-407, EC-409
Ignition coil EM-27, EC-586
Ignition control system EC-586
Ignition timing EC-70, EC-77
IGNSYS - Wiring diagram EC-587
In vehicle sensor ATC-101
INJECT - Wiring diagram EC-608
Injector EC-607
Input shaft (FF M/T) MT-20
Intake air temperature sensor EC-198, EC-221
Intake door motor ATC-107, MTC-40, MTC-68
Intake manifold EM-16
Intake manifold collector EM-16
Intake valve timing control EC-165
Intake valve timing control solenoid valve EC-423
Interior EI-32, EI-35, EI-36, EI-39, EI-40
IVC - Wiring diagram EC-424
IVIS (Infiniti vehicle immobilizer system) precautions ... GI-3

J

Joint connector (J/C) PG-49

K

Keyless entry system - See Multi-remote control system BL-45
Knock sensor (KS) EC-305
KS - Wiring diagram EC-306

L

License lamp LT-30
Line pressure test (A/T) AT-55
Liquid gasket application EM-4, LU-2, CO-2
LOAD - Wiring diagram EC-626, EC-632, EC-635
Location of electrical units PG-41
Lock, door BL-65, BL-68
Lubricant (R134a) A/C ATC-5, ATC-22, MTC-5, MTC-22
Lubrication circuit (engine) LU-4
Lubrication oil A/C ATC-137, MTC-96

M

M/T major overhaul MT-19
M/T oil replacement MT-11
M/T removal and installation MT-17
MAFS - Wiring diagram EC-184, EC-192
Magnet clutch ATC-124, MTC-83
MAIN - Wiring diagram EC-154
Mainshaft (M/T) MT-20
Maintenance (engine) MA-13
Major overhaul (Transfer) TF-50
Malfunction indicator lamp (MIL) EC-61
Mass air flow sensor (MAFS) EC-181, EC-190
Master cylinder (clutch) CL-8
Meter DI-4
METER - Wiring diagram DI-10
MI/DL - Wiring diagram EC-659
MIRROR - Wiring diagram GW-63
Misfire EC-298
Mode door control linkage adjustment ATC-113, MTC-38, MTC-74
Mode door motor ATC-113
Molding - See Exterior EI-21, EI-23, EI-24
Mud guard - See Exterior EI-23
MULTI - Wiring diagram BL-49
Multiport fuel injection (MFI) system EC-22
Multiport fuel injection precautions GI-6
Multi-remote control system BL-45

N

NATS - Wiring diagram BL-100
NVH troubleshooting (EM) EM-9
NVH troubleshooting (ST) PS-6
NVH troubleshooting (Transfer) TF-8
NVIS (Nissan vehicle immobilizer system) precautions GI-3

O

Oil cooler (engine) LU-10
Oil filter LU-9
Oil pan (engine) EM-22
Oil pressure (engine) LU-6
Oil pump (engine) LU-12
Oil pump regulator valve (engine) LU-12
Oil seal replacement (engine) . EM-49, EM-59, EM-62, EM-81
Oil seal replacement (front of final drive) RFD-9
On board diagnostic system EC-47
Operating cylinder (clutch) CL-10
ORVR (On-board Refueling Vapor Recovery) ... EC-37
Overdrive control switch AT-249
Overheat EC-480
Oversize piston EM-103

P

Park/Neutral position switch EC-540
Park/neutral position switch (A/T) AT-98
Park/neutral position switch (M/T) MT-13
Parking brake control PB-4
PCV (positive crankcase ventilation) EC-44
PGC/V - Wiring diagram EC-350, EC-506
PHASE - Wiring diagram EC-320
Pilot bushing replacement - See Pilot converter EM-81
Piston assembly EM-102
Piston pin inspection EM-98
Piston ring inspection EM-99
Piston to bore clearance EM-102
PNP/SW - Wiring diagram EC-542
POS - Wiring diagram EC-312
POWER - Wiring diagram PG-3

Power antenna AV-12
Power door lock BL-23
Power seat SE-10
Power socket WW-20
Power steering fluid level PS-7, MA-27
Power steering gear PS-17
Power steering oil pump PS-28
Power steering pressure (PSP) sensor EC-411
Power supply routing PG-2
Power window GW-33
PRE/SE - Wiring diagram EC-367, EC-374
Precations for Leak detection dye ATC-10, MTC-10
Precautions (General) GI-4
Pressure plate - See Clutch cover CL-14
Propeller shaft PR-3
Propeller shaft on vehicle service PR-3
PS/SEN - Wiring diagram EC-412

R

Radiator CO-11, CO-14
Radio - See Audio AV-4
Rear air spoiler EI-30
Rear bumper EI-16
Rear disc brake BR-31
Rear door BL-19
Rear panel finisher EI-31
Rear seat SE-24
Rear seat belt SB-4
Rear side window GW-13
Rear suspension RSU-5
Rear washer WW-12
Rear window defogger GW-17
Rear wiper WW-12
Refrigerant connection precaution ATC-6, MTC-6
Refrigerant discharging evacuating charging ATC-120, MTC-80
Refrigerant general precaution ATC-5, MTC-5
Refrigerant lines ATC-120, MTC-80
Refrigerant pressure sensor EC-619, ATC-131, MTC-90
Refrigeration cycle ATC-16, MTC-16
Release bearing (clutch) CL-12
Removal and installation (Transfer) TF-48
Reverse idler shaft (M/T) MT-20
Reverse lamp switch (M/T) - See Back-up lamp switch (M/T) MT-13
Reverse main gear (M/T) MT-20
Road test AT-57, AT-60, AT-63, AT-64
Rocker cover EM-35
RP/SEN - Wiring diagram EC-620

S

S/LOCK - Wiring diagram BL-27
SAE J1979 - Service $01 - 09 .... EC-47
SEAT - Wiring diagram SE-10
Seat belt inspection SB-6
Seat belt pre-tensioner disposal SRS-43
Seat belt, front SB-3
Seat belt, rear SB-4
Seat, front SE-17
Seat, rear SE-24
Self-diagnosis (Transfer) TF-23
SEN/PW - Wiring diagram EC-500
SHIFT - Wiring diagram AT-255
Shift control components (M/T) MT-22
Shift fork (M/T) MT-22
Shift lever MT-14
Shift lock system AT-254
Shift schedule AT-385
Side air bag (satellite) sensor SRS-40
Side window - See Rear side window GW-13
Smart entrance control unit BCS-3
SNOW MODE SW EC-652
Spark plug EM-28
Spark plug replacement MA-18
Specification value EC-143
Speedometer DI-4
Spiral cable SRS-35
SROOF - Wiring diagram RF-11
SRS - See Supplemental Restraint System SRS-6
SRS Trouble diagnoses SRS-8
Stall test (A/T) AT-52
Standardized relay PG-47
Steering gear and linkage inspection MA-27
Steering knuckle FAX-7
Steering linkage PS-17
Steering wheel and column PS-9, PS-12
Stop lamp LT-26, LT-40
Stop lamp switch EC-550
STOP/L - Wiring diagram LT-26
Strut (rear) RSU-10
Sunload sensor ATC-102
Sunroof RF-10
Supplemental Restraint System SRS-6
Suspension MA-28
Symbols and abbreviations GI-9, GI-22
Symptom matrix chart EC-103
Synchronizer (M/T) MT-20
System readiness test (SRT) code EC-52

T

Tachometer DI-4
Tail lamp LT-30
TAIL/L - Wiring diagram LT-30, LT-57
TCM inspection table AT-77
THEFT - Wiring diagram BL-81
Thermostat CO-22
Three way catalyst EM-20
Three way catalyst function EC-326
Three way catalyst precautions GI-5
Throttle body EM-19
Throttle control motor relay EC-437
Throttle position sensor (TPS) EC-210, EC-290, EC-495, EC-497, EC-570
Throwout bearing - See Clutch release bearing CL-12

Timing chain EM-49
Tire rotation MA-25
Top tether strap child restraint SB-9
Torque converter installation AT-270, AT-378
TPS1 - Wiring diagram EC-292
TPS2 - Wiring diagram EC-212
TPS3 - Wiring diagram EC-572
Transmission case (M/T) MT-19
Trouble diagnoses GI-10
TURN - Wiring diagram LT-19
Turn signal lamp LT-17
Two trip detection logic EC-47

V

Vacuum hose (brake system) BR-24
Vacuum hose drawing (Engine control) EC-112
Valve clearance EM-46
Valve guide EM-69
Valve lifter EM-37
Valve seat EM-71
Valve spring EM-72
Variable induction air control system (VIAS) .. EC-545, EC-597
VDC -Wiring diagram BRC-53
Vehicle speed sensor (VSS) EC-405, EC-538
VENT/V - Wiring diagram EC-357, EC-514
VIAS - Wiring diagram EC-599
VIAS/V - Wiring diagram EC-546
VIN registration EC-87

W

Washer, rear WW-12
Water control valve CO-22
Water pump CO-20
Water temperature gauge DI-4
Weatherstrip - See Exterior BL-22
Wheel alignment (front) FSU-6
Wheel balance WT-5, MA-24
Wheel bearing (front axle) FAX-7
Wheel bearing (rear) RAX-5, RAX-15
Wheel hub (front) FAX-7
WINDOW - Wiring diagram GW-39
Window, back GW-15
Window, back door GW-15
Window, door GW-56, GW-59
Window, rear side GW-13
Window, side - See Rear side window GW-13
WIP/R - Wiring diagram WW-12
Wiper, rear WW-12
Wiring Diagram (Cell code) list PG-38
Wiring diagrams GI-14
Withdrawal lever (clutch) CL-12
Wrist pin - See Piston pin inspection EM-98